

# How to remove the Matrix Band

See how to remove the McDonald Matrix Band in two manageable steps.

## Step one:

Use the Hex Stick to loosen the McDonald Matrix Band toggle.



## Step two:

Use a fine bur or scissors to cut the band lingually, then remove by pulling the band through from the buccal aspect.

